

Product Description

Range :- (0 ~ +1000)kg./cm²

When calibrating pressure measuring and controlling instruments including pressure gauges and pressure calibrators , it is essential that a stable pressure source of generating requisite pressure is available at hand. We provide all types of hand operated pumps to fulfill this need.



Technical Specifications

Model No.	EN-HPP1000S
Range	(0 ~ +1000)kg./cm ²
Flexible Hose and Assorted Fittings	Supplied
Weight	2.5kgs. Approx.

All product specifications are subject to change without prior notice.

Operation

Pressure is generated by the hand operation of the caliper handle which move a piston back and forth resulting in the suction and delivery fluid used for pressure generation. Suitable for use with Water/Oil.

Application

Useful for the testing and calibration of Pressure , Transmitters both in the Lab. and Field.

Supply Includes

Supply includes EN-HPP1000S Hand Pump with 1 No. Flexible Hose and Set of Assorted Fittings which suits most of the gauges available in the market.

Note

The Flexible Hose supplied can only be used Upto - 400kg./cm² & above this , the Gauge to be Fixed in the Pump itself.

All product specifications are subject to change without prior notice.