

Product Description

Range :- Vacuum : (Amb. To -0.85)kg./cm² & Pressure : (Amb. To +30.0)kg./cm²

When calibrating pressure measuring and controlling instruments including pressure gauges and pressure calibrators , it is essential that a stable pressure source of generating requisite pressure is available at hand. We provide all types of hand operated pumps to fulfill this need.



Technical Specifications

Model No.	EN-HPP30D
Range	Vacuum : (Amb. To -0.85)kg./cm ² & Pressure : (Amb. To +30.0)kg./cm ²
Flexible Hose and Assorted Fittings	Supplied
Weight	< 1.5kgs. approx.

All product specifications are subject to change without prior notice.

**Operation**

Pressure or Vacuum is generated by the hand operation of the Caliper Handle which move a piston back and forth resulting in the development of pressure or vacuum. The Pressure or Vacuum mode selection option is available.

Application

Useful for the Testing and Calibration of Pressure and Vacuum Gauges , Transmitters both in the Lab. and Field.

Supply Includes

Supply includes EN-HPP30D Hand Pump with 1 No. Flexible Hose and set of Assorted Fittings which suits most of the gauges available in the market.

All product specifications are subject to change without prior notice.